



TECHNICAL SPECIFICATIONS



PRSL 1
PRSL 2
PRSL 3
PRSL 5



PRST 1
PRST 2
PRST 3
PRST 5

JOINT WIDTH
E.g. 2 Holes = 2mm



PRSC 1
PRSC 2
PRSC 3
PRSC 5



PRST

GROSS PRICE LIST

LINEAR LEVELER PROLEVELING SYSTEM

Article	thick mm	Pack Pcs.	Box
PRSL 1	1	100	3000 Pcs
PRSL 2	2	100	3000 Pcs
PRSL 3	3	100	3000 Pcs
PRSL 5	5	100	3000 Pcs

"T" LEVELER PROLEVELING SYSTEM

Article	thick mm	Pack Pcs.	Box
PRST 1	1	100	3000 Pcs
PRST 2	2	100	3000 Pcs
PRST 3	3	100	3000 Pcs
PRST 5	5	100	3000 Pcs

CROSS LEVELER PROLEVELING SYSTEM

Article	thick mm	Pack Pcs.	Box
PRSC 1	1	100	3000 Pcs
PRSC 2	2	100	3000 Pcs
PRSC 3	3	100	3000 Pcs
PRSC 5	5	100	3000 Pcs

THE HOLES ON THE LEVELER INDICATE THE WIDTH OF THE JOINT

PROLEVELING SYSTEM REMOVER for LEVELER

Article	Pack Pcs.	Box
PRSSV	50	550 Pz



PRSSV

ROTATING POMMEL CAP FOR LEVELER PROLEVELING SYSTEM

Article	Pack Pcs.	Box
PRST	50	1000 Pcs



PROTECTION CAP FOR PROLEVELING SYSTEM

Article	Pack Pcs.	Box
PRSPC	50	2500 Pcs





It protects the marble and natural stones surface from scratches that could be provoked by the cap during the floor levelling.

Tiles cm x cm	30 X 30	40 X 40	45 X 45	50 X 50	60 X 60	80 X 80	90 X 90	120 X 120
U. / MQ (Type of leveler)*	11 (only +)	6 (only +)	5 (only +)	4 (only +)	3 (only +)	5 (2+, 3L)	5 (2+, 3L)	3 (1+, 2L)



* + = cross leveler, L = linear leveler, T = "T" shape leveler

Tiles cm x cm	30 X 60	40 X 80	45 X 90	120 X 30	100 X 50	120 X 60
U. / MQ (Type of leveler)*	6 (only +)	6 (3+, 3L)	6 (3+, 3L)	6 (3+, 3L)	4 (2+, 2L)	4 (2+, 2L)



* + = cross leveler, L = linear leveler, T = "T" shape leveler

Tiles cm x cm	10 X 100	12 X 100	15 X 100	20 X 100	10 X 120	12 X 120	15 X 120	20 X 120	10 X 80	12 X 80	15 X 80	20 X 80	40 x 80	45 x 90	100 x 50	120 x 60
U. / MQ (Type of leveler)*	20 (only T)	17 (only T)	14 (only T)	10 (only T)	17 (only T)	14 (only T)	11 (only T)	9 (only T)	25 (only T)	21 (only T)	17 (only T)	13 (only T)	6 (only T)	5 (only T)	4 (only T)	4 (only T)

* + = cross leveler, L = linear leveler, T = "T" shape leveler



10x100
12x100
15x100
20x100
10x120
12x120

15x120
20x120
10x80
12x80
15x80
20x80

40x80
45x90
100x50
120x60